


Systems Description


Electrical Connections [With CATA]

- FUSES
 ① ECU (10 A)*
 ② No. 2 (15 A)
 ③ No. 9 (7.5 A)
 ④ No. 7 (7.5 A)
 ⑤ No. 1 (10 A)
 ⑥ BACK UP (7.5 A)*
 ⑦ IG (50 A)*
 ⑧ BATTERY (80 A)*
 * In the main fuse box



- A: BYPASS CONTROL SOLENOID VALVE (2.2 ℓ)
 B: INTAKE CONTROL SOLENOID VALVE
 C: EGR CONTROL SOLENOID VALVE
 D: PURGE CUT-OFF SOLENOID VALVE

NOT USED



TERMINAL LOCATION



Electrical Connections [Without CATA]

