



Water Pump

Illustrated Index

NOTE:

- Use new O-rings and new special bolts when reassembling.
- Use liquid gasket, Part No. 0Y740-99986.

D16Y3, D14A2 engines:

**ECT GAUGE
SENDING UNIT**
9 N·m (0.9 kgf·m,
7 lbf·ft)
Apply liquid gasket
to the threads.

BLEED BOLT
10 x 1.25 mm
9.8 N·m (1.0 kgf·m, 7.2 lbf·ft)

6 x 1.0 mm
9.8 N·m (1.0 kgf·m,
7.2 lbf·ft)

**ENGINE COOLANT
TEMPERATURE (ECT)
SENSOR**
18 N·m (1.8 kgf·m,
13 lbf·ft)

O-RING
Replace.

**WATER OUTLET
COVER**
Apply liquid gasket
to mating surface.

D16Y2, D15Z3 engines:

**ECT GAUGE
SENDING UNIT**
9 N·m (0.9 kgf·m,
7 lbf·ft)
Apply liquid gasket
to the threads.

BLEED BOLT
10 x 1.25 mm
9.8 N·m (1.0 kgf·m, 7.2 lbf·ft)

6 x 1.0 mm
9.8 N·m (1.0 kgf·m,
7.2 lbf·ft)

**ENGINE COOLANT
TEMPERATURE (ECT)
SENSOR**
18 N·m (1.8 kgf·m,
13 lbf·ft)

O-RING
Replace.

**WATER OUTLET
COVER**
Apply liquid gasket
to mating surface.

