

# Component Locations



## Index

### MASTER CYLINDER

Removal, page 19-13

Disassembly, page 19-13

Reassembly, page 19-15

Pushrod Clearance Adjustment, page 19-18

Installation, page 19-19

### BRAKE BOOSTER

Inspection, page 19-19

Replacement, 19-21

### BRAKE PEDAL


Inspection and  
Adjustment, page 19-4

### PARKING BRAKE

Adjustment, page 19-5

### PARKING BRAKE CABLE

Inspection and Replacement, page 19-39



### FRONT BRAKES

Front Brake Pads, page 19-7

Front Brake Disc, page 19-9

Front Brake Caliper, page 19-10

### BRAKE HOSES/PIPES

Inspection, page 19-37

Hose Replacement, page 19-38

### REAR DRUM BRAKE

Index/Inspection, page 19-32

### REAR BRAKE SHOES

Inspection, page 19-33

Disassembly, page 19-34

Reassembly, page 19-35

### WHEEL CYLINDER

Disassembly and Inspection, page 19-36

### REAR DISC BRAKES

Rear Brake Pads, page 19-21

Rear Brake Disc, page 19-24

Rear Brake Caliper, page 19-25