


Fuses

Under-hood ABS Fuse/Relay Box

NOTE: LHD type is shown, RHD type is similar.



Fuse Number	Amps	Wire Color	Component(s) or Circuit(s) Protected
51	40 A	—	ABS pump motor relay (contacts)
52	10 A	BRN/YEL	ABS control unit (MCK)
53	20 A	WHT/GRN	ABS front solenoids
54	15 A	WHT	ABS rear solenoids, ABS control unit (B2)
55	—	—	Not used