

Oil Pump

Overhaul

NOTE:

- Use new O-rings when reassembling.
- Apply oil to O-rings before installation.
- Use liquid gasket, Part No. 0Y740 – 99986.
- The rotors must be installed to the same direction in order.
- After reassembly, check that the rotors move without binding.

