


Rear View Mirror

Replacement

1. Remove the rubber damper.
2. Pry the cover off using the end of a slot-head screwdriver.



3. Remove both mounting screws from the mirror base, then remove the mirror assembly.
4. Remove the base from the rear view mirror.

