

Special Tools

Special Tools (Common with Other Models)

21. Brake				
Ref. No.	Tool Number	Description	Q'ty	Remarks
*①	07GAG—SE00100	Brake Booster Adjustment Gauge	1	Component Tools 07510—6340400 may also be used. 07949—6110000 may also be used.
②	07504—6340100	Brake Booster Tool Set	1	
②-1	07404—5790300	Vacuum Gauge	(1)	
②-2	07406—5790200	Oil Pressure Gauge	(2)	
②-3	07410—5790100	Pressure Gauge Attachment, C	(1)	
②-4	07410—5790500	Tube Joint Attachment, I	(1)	
②-5	07510—6340100	Pressure Gauge Joint Pipe	(2)	
②-6	07510—6340300	Vacuum Joint Tube, A	(1)	
③	07749—0010000	Driver	1	
④	07914—SA50000	Snap Ring Pliers	1	
⑤	07921—0010100	Flare Nut Wrench	1	
⑥	07947—6890300	Driver Attachment, C	1	
⑦	07965—5790300	Cup Guide	1	
⑧	07975—SA50002	Brake Booster Rod Adjustment Gauge	1	

* ZC1 Engine Only

22. Body				
Ref. No.	Tool Number	Description	Q'ty	Remarks
①	07GAZ—SE30100	Torsion Rod Assembly Tool	1	4D Only
②	07703—0010300	Torx Driver Grip	1	2D H/B Only
③	07703—0010600	Torx Bit Driver, T-30HD	1	2D H/B Only

24. Air Conditioner				
Ref. No.	Tool Number	Description	Q'ty	Remarks
①	07GAB—PJ60100	A/C Clutch Holder	1	07923—PB80001 may also be used.
②	07703—0010300	Torx Bit Driver, T-30HD	1	07703—0010200 may also be used.
③	07934—PB80001	A/C Clutch Puller	1	
④	07934—SB20000	Shaft Seal Driver	1	

Optional Tools

Ref. No.	Tool Number	Description	Q'ty	Remarks
①	07780—0010300	Valve Seat Cutter, 45°	1	ZC1 EX
	07780—0010400	Valve Seat Cutter, 45°	1	Except ZC1 EX
②	07780—0010800	Valve Seat Cutter, 45°	1	IN
③	07780—0012200	Valve Seat Cutter, 30°	1	ZC1 IN & EX
	07780—0012300	Valve Seat Cutter, 30°	1	Except ZC1 EX
④	07780—0012900	Valve Seat Cutter, 30°	1	Except ZC1 IN
⑤	07780—0014000	Valve Seat Cutter, 60°	1	ZC1 IN & EX, Except ZC1 IN
⑥	07780—0014100	Valve Seat Cutter, 60°	1	Except ZC1 EX
⑦	07781—0010201	Valve Seat Cutter Holder	1	