


Wire Harness and Ground Locations



Engine Compartment

LHD type:




(cont'd)

Wire Harness and Ground Locations


Engine Compartment (cont'd)

RHD type:






NOTE: LHD type is shown, RHD type is similar.



Wire Harness and Ground Locations

Engine Compartment (cont'd)


LHD type:





RHD type:

T: ABS MODULATOR UNIT WIRE HARNESS



G: ENGINE COMPARTMENT WIRE HARNESS


G202

G201

Wire Harness and Ground Locations

Engine Compartment (cont'd)

LHD type:





RHD type:

