

# Brakes

## Index

### BRAKE HOSE/LINE

- Inspection, page 21-29

### BRAKE BOOSTER

- Index/Inspection, page 21-15
- Testing, page 21-16
- Disassembly, page 21-17
- Rebuild kit, page 21-18
- Reassembly, page 21-19
- Pushrod Clearance Adjustment, page 21-23

### BRAKE LIGHT SWITCH

- Pedal Height Adjustment, page 21-3
- Inspection, page 21-31

### MASTER CYLINDER

- Overhaul/Inspection, page 21-12
- Disassembly, page 21-13
- Reassembly, page 21-14
- Brake Fluid Level Switch, page 21-32

### DUAL PROPORTIONING VALVE

- Index, page 21-11

### FRONT BRAKE

- Inspection, page 21-4, 5
- Brake Pad Inspection/Replacement, page 21-6
- Brake Caliper Disassembly, page 21-7
- Brake Disc Inspection, page 21-9

### PARKING BRAKE

- Adjustment, page 21-3
- Disassembly/Reassembly, page 21-30

### REAR BRAKE

- Inspection, page 21-25
- Brake Shoe Removal, page 21-26
- Wheel Cylinder Disassembly/Inspection, page 21-27
- Brake Shoe Reassembly, page 21-28

