



MAIN RELAY

101	100	99
G/B1	Bu/W	B1
Y	B1/Y	Y/B1
105	104	103

PA SENSOR

R/W
Y/R
Br/W

MAP SENSOR

326	W
249	R
250	Br/W

ENGINE SUB HARNESS CONNECTOR

35	Br/B1	B1/R
41	G/B1	Br/B1
26	R/Y	R/W
40	R/Bu	Y/R
31	W/Bu	Or
30	W	Or/Bu
29	Y	Y

IMA SENSOR

252	W/Y
Y/R	
Br/B1	

RESISTOR

33	Br	R	Lb
34	Y		
38			

RESISTOR (COMMON)

77	Y/B1
----	------

CONTROL UNIT CONNECTOR A

7	Bu/W
13	G/Or
20	W/Y

CONTROL UNIT CONNECTOR B

21	22	23	24	25	26	27	28
Or	Or/Bu	R/Y	R/Bu	R/W	W	Y/R	R
W	W/Bu	R/W		Br/B1	Br/W		
29	30	31	34	35			

17	16	15	14	11	10
Br	R	Lb	Y	Y/B1	W/G
B1	B1	R	G/B1	Br/B1	B1/R
9	8	6	4	2	1