



# Vacuum Connections

KX, KG






## Control Box




# Vacuum Connections

KQ






## Control Box




# Vacuum Connection

KE






## Control Box




KB, KF






## Control Box





# Vacuum Connections

KG, KX




- ① FRONT OXYGEN (O<sub>2</sub>) SENSOR
- ② REAR OXYGEN (O<sub>2</sub>) SENSOR
- ③ MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR
- ④ EGR VALVE
- ⑤ EGR VALVE LIFT SENSOR
- ⑥ CONSTANT VACUUM CONTROL (CVC) VALVE
- ⑦ AIR CHAMBER
- ⑧ EGR CONTROL SOLENOID VALVE
- ⑨ ELECTRONIC AIR CONTROL VALVE (EACV)
- ⑩ FAST IDLE VALVE
- ⑪ IDLE ADJUSTING SCREW
- ⑫ DASHPOT DIAPHRAGM
- ⑬ DASHPOT CHECK VALVE
- ⑭ AIR FILTER
- ⑮ AIR CLEANER
- ⑯ FUEL INJECTOR
- ⑰ PRESSURE REGULATOR
- ⑱ PRESSURE REGULATOR CUT-OFF SOLENOID VALVE
- ⑲ FUEL FILTER

- ⑳ FUEL PUMP
- ㉑ FUEL TANK
- ㉒ AIR SUCTION VALVE
- ㉓ AIR SUCTION CONTROL SOLENOID VALVE
- ㉔ VACUUM TANK A
- ㉕ VACUUM TANK B
- ㉖ CHECK VALVE A
- ㉗ CHECK VALVE B
- ㉘ BYPASS CONTROL SOLENOID VALVE A
- ㉙ BYPASS CONTROL SOLENOID VALVE B
- ㉚ PCV VALVE
- ㉛ BREATHER CHAMBER
- ㉜ CHARCOAL CANISTER
- ㉝ TWO-WAY VALVE
- ㉞ THERMOVALVE
- ㉟ BYPASS CONTROL DIAPHRAGM
- ㊱ VACUUM CONTROL DIAPHRAGM
- ㊲ RESONATOR CONTROL SOLENOID VALVE
- ㊳ CHECK VALVE C
- ㊴ SURGE TANK



KB, KE, KF




- ① MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR
- ② EGR VALVE
- ③ EGR VALVE LIFT SENSOR
- ④ CONSTANT VACUUM CONTROL (CVC) VALVE
- ⑤ AIR CHAMBER
- ⑥ EGR CONTROL SOLENOID VALVE
- ⑦ ELECTRONIC AIR CONTROL VALVE (EACV)
- ⑧ FAST IDLE VALVE
- ⑨ IDLE ADJUSTING SCREW
- ⑩ DASHPOT DIAPHRAGM
- ⑪ DASHPOT CHECK VALVE
- ⑫ AIR FILTER
- ⑬ AIR CLEANER
- ⑭ FUEL INJECTOR
- ⑮ PRESSURE REGULATOR
- ⑯ PRESSURE REGULATOR CUT-OFF SOLENOID VALVE
- ⑰ FUEL FILTER

- ⑱ FUEL PUMP
- ⑲ FUEL TANK
- ⑳ VACUUM TANK A
- ㉑ CHECK VALVE A
- ㉒ BYPASS CONTROL SOLENOID VALVE A
- ㉓ BYPASS CONTROL SOLENOID VALVE B
- ㉔ PCV VALVE
- ㉕ BREATHER CHAMBER
- ㉖ CHARCOAL CANISTER
- ㉗ TWO-WAY VALVE
- ㉘ THERMOVALVE
- ㉙ BYPASS CONTROL DIAPHRAGM
- ㉚ RESONATOR CONTROL DIAPHRAGM
- ㉛ RESONATOR CONTROL SOLENOID VALVE
- ㉜ CHECK VALVE C
- ㉝ SURGE TANK

# Vacuum Connections

KQ



- ① FRONT OXYGEN (O<sub>2</sub>) SENSOR
- ② REAR OXYGEN (O<sub>2</sub>) SENSOR
- ③ MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR
- ④ ELECTRONIC AIR CONTROL VALVE (EACV)
- ⑤ FAST IDLE VALVE
- ⑥ IDLE ADJUSTING SCREW
- ⑦ DASHPOT DIAPHRAGM
- ⑧ DASHPOT CHECK VALVE
- ⑨ AIR FILTER
- ⑩ FUEL INJECTOR
- ⑪ PRESSURE REGULATOR
- ⑫ PRESSURE REGULATOR CUT-OFF SOLENOID VALVE
- ⑬ FUEL FILTER
- ⑭ FUEL PUMP
- ⑮ FUEL TANK

- ⑯ VACUUM TANK A
- ⑰ CHECK VALVE A
- ⑱ BYPASS CONTROL SOLENOID VALVE A
- ⑲ BYPASS CONTROL SOLENOID VALVE B
- ⑳ PCV VALVE
- ㉑ BREATHER CHAMBER
- ㉒ CHARCOAL CANISTER
- ㉓ TWO-WAY VALVE
- ㉔ THERMOVALVE
- ㉕ BYPASS CONTROL DIAPHRAGM
- ㉖ RESONATOR CONTROL DIAPHRAGM
- ㉗ RESONATOR CONTROL SOLENOID VALVE
- ㉘ CHECK VALVE C
- ㉙ SURGE TANK
- ㉚ AIR CLEANER