


Position of Parts in Body <RHD>



- R 2 Rear Height Control Sensor Sub-Assembly LH

- T 1 Visor Assembly RH
- T 2 Vanity Light Assembly RH
- T 3 Visor Assembly LH
- T 4 Vanity Light Assembly LH
- T 5 No. 1 Room Light Assembly
- T 6 Map Light Assembly
- T 7 Rain Sensor
- T 8 Inner Rear View Mirror Assembly
- T 9 Inner Rear View Mirror Assembly
- T 10 Sliding Roof Control ECU
- T 11 A/C Thermistor Assembly

- U 1 Rear No. 1 Ultrasonic Sensor RH
- U 2 Rear No. 1 Ultrasonic Sensor LH
- U 3 Rear No. 1 Ultrasonic Sensor Center RH
- U 4 Rear No. 1 Ultrasonic Sensor Center LH
























- V 1 Rear Wiper Motor Assembly
- V 2 Rear Light Assembly RH
- V 3 Noise Filter (Defogger)
- V 4 Back Door Opener Switch Assembly
- V 5 License Plate Light Assembly RH
- V 6 License Plate Light Assembly LH
- V 7 Rear Window Defogger (Back Door Glass)
- V 8 Rear Television Camera Assembly
- V 9 Rear Light Assembly LH
- V 10 Rear Window Defogger (Back Door Glass) , Rear Window Defogger (Glass Breakage Sensor)

- a 1 Center Stop Light Assembly

- b 1 Rear Speed Sensor LH
- b 2 Rear Speed Sensor RH

- z 6 Outer Mirror Control ECU Assembly LH , Outer Rear View Mirror Assembly LH
- z 7 Outer Mirror Control ECU Assembly RH , Outer Rear View Mirror Assembly RH
- z 17 Seat Memory Switch RH

Position of Parts in Body <RHD>



Position of Parts in Body <RHD>

