

J POWER SOURCE (Current Flow Chart)

Engine Room No.1 R/B (See Page 81)

Fuse		System	Page
7.5A	A/C IG	Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
7.5A	EFI NO.2	Engine Control (LHD)	212
		Engine Control (RHD)	224
7.5A	FR IG	Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Back-Up Light (LHD)	392
		Back-Up Light (RHD)	394
		Charging (LHD)	204
		Charging (RHD)	208
		Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
		Headlight Cleaner (LHD)	826
		Headlight Cleaner (RHD)	828
		LEXUS Park Assist (Clearance Sonar) [LHD]	726
		LEXUS Park Assist (Clearance Sonar) [RHD]	732
		Power Seat (Rear Passenger's Seat) [LHD]	762
		Power Seat (Rear Passenger's Seat) [RHD]	770
		Radiator Fan (LHD)	874
		Radiator Fan (RHD)	876
		Rear Window Defogger (LHD)	830
		Rear Window Defogger (RHD)	832
		Remote Control Mirror (LHD)	598
		Remote Control Mirror (RHD)	606
7.5A	IGN	Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
		Engine Control (LHD)	212
		Engine Control (RHD)	224
7.5A	STA	ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
		Engine Control (LHD)	212
		Engine Control (RHD)	224
		Starting and Ignition (LHD)	196
		Starting and Ignition (RHD)	200
7.5A	TAIL	Automatic Light Control (LHD)	444
		Automatic Light Control (RHD)	448
		Light Auto Turn Off (LHD)	452
		Light Auto Turn Off (RHD)	458

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
7.5A	TAIL	Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Taillight (LHD)	372
		Taillight (RHD)	378
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
10A	ETCS	Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
		Engine Control (LHD)	212
		Engine Control (RHD)	224
10A	HORN	Horn (LHD)	814
		Horn (RHD)	816
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
10A	INJ	Engine Control (LHD)	212
		Engine Control (RHD)	224
		Starting and Ignition (LHD)	196
		Starting and Ignition (RHD)	200
15A	FR FOG	Front Fog Light (LHD)	364
		Front Fog Light (RHD)	368
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
15A	H-LP L LWR	Headlight (LHD)	356
		Headlight (RHD)	360
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
15A	H-LP R LWR	Headlight (LHD)	356
		Headlight (RHD)	360
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
20A	H-LP HI	Headlight (LHD)	356
		Headlight (RHD)	360
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
20A	WASHER	Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628
30A	EFI NO.1	Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
		Engine Control (LHD)	212
		Engine Control (RHD)	224
30A	H-LP. CLN	Headlight Cleaner (LHD)	826
		Headlight Cleaner (RHD)	828
30A	WIP	Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628

Engine Room No.3 R/B (See Page 83)

Fuse		System	Page
7.5A	ABS 3	VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672

Fusible Link Block (See Page 84, 85)

Fuse		System	Page
5A	ALT-S	Charging (LHD)	204
		Charging (RHD)	208
30A	AM 2	Engine Control (LHD)	212
		Engine Control (RHD)	224
		Starting and Ignition (LHD)	196
		Starting and Ignition (RHD)	200
40A	ABS 1	VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672
40A	ABS 2	VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672
40A	AIR SUS	Electronic Modulated Air Suspension (LHD)	694
		Electronic Modulated Air Suspension (RHD)	704
40A	DEFOG	Rear Window Defogger (LHD)	830
		Rear Window Defogger (RHD)	832
50A	FAN	Radiator Fan (LHD)	874
		Radiator Fan (RHD)	876
50A	HEATER	Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
50A	LUG J/B	Automatic Light Control (LHD)	444
		Automatic Light Control (RHD)	448

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
50A	LUG J/B	Back-Up Light (LHD)	392
		Back-Up Light (RHD)	394
		Light Auto Turn Off (LHD)	452
		Light Auto Turn Off (RHD)	458
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
		Rear Fog Light (LHD)	396
		Rear Fog Light (RHD)	400
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Stop Light (LHD)	384
		Stop Light (RHD)	388
		Taillight (LHD)	372
		Taillight (RHD)	378
80A	FAN	Radiator Fan (LHD)	874
		Radiator Fan (RHD)	876
140A	ALT	Charging (LHD)	204
		Charging (RHD)	208
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294

Driver Side J/B (See Page 86, 98)

Fuse		System	Page
5A	D B/ANC	Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Power Shoulder Belt Anchorage (LHD)	586
		Power Shoulder Belt Anchorage (RHD)	592
5A	STOP	Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
		Electronic Modulated Air Suspension (LHD)	694
		Electronic Modulated Air Suspension (RHD)	704
		Engine Control (LHD)	212
		Engine Control (RHD)	224
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Power Seat (Rear Passenger's Seat) [LHD]	762
		Power Seat (Rear Passenger's Seat) [RHD]	770
		Shift Lock (LHD)	722
		Shift Lock (RHD)	724

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
5A	STOP	Stop Light (LHD)	384
		Stop Light (RHD)	388
		VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672
7.5A	A/C	Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
7.5A	ABS-IG	VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672
7.5A	AM1	Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
7.5A	D-ACC	Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Multiplex Communication System (Communication Bus) [LHD]	252
		Multiplex Communication System (Communication Bus) [RHD]	258
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Power Window (LHD)	542
		Power Window (RHD)	550
		Remote Control Mirror (LHD)	598
		Remote Control Mirror (RHD)	606
		Shift Lock (LHD)	722
		Shift Lock (RHD)	724
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
7.5A	GAUGE	Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
		Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Charging (LHD)	204
		Charging (RHD)	208
		Combination Meter (LHD)	862
		Combination Meter (RHD)	868
		Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
		Electronic Modulated Air Suspension (LHD)	694
		Electronic Modulated Air Suspension (RHD)	704
		Engine Control (LHD)	212
		Engine Control (RHD)	224

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
7.5A	GAUGE	Front Fog Light (LHD)	364
		Front Fog Light (RHD)	368
		Headlight (LHD)	356
		Headlight (RHD)	360
		Headlight Beam Level Control (LHD)	714
		Headlight Beam Level Control (RHD)	718
		Illumination (LHD)	412
		Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Key Reminder and Seat Belt Warning (LHD)	578
		LEXUS Navigation System (LHD)	842
		LEXUS Navigation System (RHD)	846
		LEXUS Park Assist (Clearance Sonar) [LHD]	726
		LEXUS Park Assist (Clearance Sonar) [RHD]	732
		Luggage Compartment Door Opener and Closer (LHD)	566
		Luggage Compartment Door Opener and Closer (RHD)	570
		Moon Roof (LHD)	558
		Moon Roof (RHD)	562
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Radio and Player (LHD)	850
		Radio and Player (RHD)	856
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
		Rear Fog Light (LHD)	396
		Rear Fog Light (RHD)	400
		Seat Belt Warning (RHD)	582
		Shift Lock (LHD)	722
		Shift Lock (RHD)	724
		SRS (LHD)	679
		SRS (RHD)	687
		Stop Light (LHD)	384
		Stop Light (RHD)	388
		Taillight (LHD)	372
		Taillight (RHD)	378
		VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628
7.5A	MPX-IG	Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Automatic Light Control (LHD)	444
		Automatic Light Control (RHD)	448

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
7.5A	MPX-IG	Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Front Fog Light (LHD)	364
		Front Fog Light (RHD)	368
		Headlight (LHD)	356
		Headlight (RHD)	360
		Illumination (LHD)	412
		Illumination (RHD)	420
		Light Auto Turn Off (LHD)	452
		Light Auto Turn Off (RHD)	458
		Mirror Heater (LHD)	614
		Mirror Heater (RHD)	618
		Multiplex Communication System (Communication Bus) [LHD]	252
		Multiplex Communication System (Communication Bus) [RHD]	258
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Power Seat (Driver's Seat) [LHD]	746
		Power Seat (Driver's Seat) [RHD]	750
		Power Shoulder Belt Anchorage (LHD)	586
		Power Shoulder Belt Anchorage (RHD)	592
		Power Tilt and Power Telescopic (LHD)	738
		Power Tilt and Power Telescopic (RHD)	742
		Power Window (LHD)	542
		Power Window (RHD)	550
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
		Rear Fog Light (LHD)	396
		Rear Fog Light (RHD)	400
		Remote Control Mirror (LHD)	598
		Remote Control Mirror (RHD)	606
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		SRS (LHD)	679
		SRS (RHD)	687
		Taillight (LHD)	372
		Taillight (RHD)	378
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Turn Signal and Hazard Warning Light (LHD)	404
		Turn Signal and Hazard Warning Light (RHD)	408
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
7.5A	MPX-IG	Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
7.5A	OBD	Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
		Electronic Modulated Air Suspension (LHD)	694
		Electronic Modulated Air Suspension (RHD)	704
		Engine Control (LHD)	212
		Engine Control (RHD)	224
		VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672
7.5A	PANEL	Clock (LHD w/o LEXUS Navigation System)	810
		Clock (RHD w/o LEXUS Navigation System)	812
		Illumination (LHD)	412
		Illumination (RHD)	420
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
7.5A	SECURITY	Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Horn (LHD)	814
		Horn (RHD)	816
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Power Window (LHD)	542
		Power Window (RHD)	550
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
7.5A	TEL	Cellular Mobile Telephone (RHD)	838
		LEXUS Navigation System (RHD)	846
		Radio and Player (RHD)	856
10A	D RR-IG	Vibration Seat (LHD)	798
		Vibration Seat (RHD)	802
15A	D S/HTR	Climate Control Seat (LHD)	778
		Climate Control Seat (RHD)	782

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
15A	D S/HTR	Seat Heater (Front) [LHD]	786
		Seat Heater (Front) [RHD]	788
15A	D-CIG	Cigarette Lighter and Power Outlet (LHD)	806
		Cigarette Lighter and Power Outlet (RHD)	808
15A	POWER OUTLET	Cigarette Lighter and Power Outlet (LHD)	806
		Cigarette Lighter and Power Outlet (RHD)	808
20A	AIRSUS	Electronic Modulated Air Suspension (LHD)	694
		Electronic Modulated Air Suspension (RHD)	704
20A	TI & TE	Power Tilt and Power Telephone (LHD)	738
		Power Tilt and Power Telephone (RHD)	742
30A	AMP	Radio and Player (RHD)	856
30A	D P/SEAT	Power Seat (Driver's Seat) [LHD]	746
		Power Seat (Driver's Seat) [RHD]	750

Passenger Side J/B (See Page 92, 104)

Fuse		System	Page
5A	H-LP LVL	Headlight Beam Level Control (LHD)	714
		Headlight Beam Level Control (RHD)	718
5A	P B/ANC	Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Power Shoulder Belt Anchorage (LHD)	586
		Power Shoulder Belt Anchorage (RHD)	592
7.5A	CRT	LEXUS Navigation System (LHD)	842
		LEXUS Navigation System (RHD)	846
7.5A	IG2	Engine Immobiliser and Steering Lock System (LHD w/ Smart Key System)	236
		Engine Immobiliser and Steering Lock System (RHD w/ Smart Key System)	240
		Engine Immobiliser System (LHD w/o Smart Key System)	244
		Engine Immobiliser System (RHD w/o Smart Key System)	248
		SRS (LHD)	679
		SRS (RHD)	687
7.5A	MPX-B1	Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Engine Immobiliser and Steering Lock System (LHD w/ Smart Key System)	236
		Engine Immobiliser and Steering Lock System (RHD w/ Smart Key System)	240
		Engine Immobiliser System (LHD w/o Smart Key System)	244
		Engine Immobiliser System (RHD w/o Smart Key System)	248
		Mirror Heater (LHD)	614
		Mirror Heater (RHD)	618
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Power Seat (Driver's Seat) [LHD]	746

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
7.5A	MPX-B1	Power Seat (Driver's Seat) [RHD]	750
		Power Seat (Rear Passenger's Seat) [LHD]	762
		Power Seat (Rear Passenger's Seat) [RHD]	770
		Power Shoulder Belt Anchorage (LHD)	586
		Power Shoulder Belt Anchorage (RHD)	592
		Power Window (LHD)	542
		Power Window (RHD)	550
		Remote Control Mirror (LHD)	598
		Remote Control Mirror (RHD)	606
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Vibration Seat (LHD)	798
		Vibration Seat (RHD)	802
		Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
7.5A	MPX-B2	Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Cellular Mobile Telephone (LHD)	834
		Charging (LHD)	204
		Charging (RHD)	208
		Combination Meter (LHD)	862
		Combination Meter (RHD)	868
		Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
		Electronic Modulated Air Suspension (LHD)	694
		Electronic Modulated Air Suspension (RHD)	704
		Engine Control (LHD)	212
		Engine Control (RHD)	224
		Front Fog Light (LHD)	364
		Front Fog Light (RHD)	368
		Headlight (LHD)	356
		Headlight (RHD)	360
		Headlight Beam Level Control (LHD)	714
		Headlight Beam Level Control (RHD)	718
		Illumination (LHD)	412
		Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Key Reminder and Seat Belt Warning (LHD)	578
		LEXUS Navigation System (LHD)	842

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
7.5A	MPX-B2	LEXUS Navigation System (RHD)	846
		LEXUS Park Assist (Clearance Sonar) [LHD]	726
		LEXUS Park Assist (Clearance Sonar) [RHD]	732
		Luggage Compartment Door Opener and Closer (LHD)	566
		Luggage Compartment Door Opener and Closer (RHD)	570
		Moon Roof (LHD)	558
		Moon Roof (RHD)	562
		Multiplex Communication System (Communication Bus) [LHD]	252
		Multiplex Communication System (Communication Bus) [RHD]	258
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Radio and Player (LHD)	850
		Radio and Player (RHD)	856
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
		Rear Fog Light (LHD)	396
		Rear Fog Light (RHD)	400
		Seat Belt Warning (RHD)	582
		SRS (LHD)	679
		SRS (RHD)	687
		Stop Light (LHD)	384
		Stop Light (RHD)	388
		Taillight (LHD)	372
		Taillight (RHD)	378
		VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628
7.5A	MPX-B3	Automatic Light Control (LHD)	444
		Automatic Light Control (RHD)	448
		Front Fog Light (LHD)	364
		Front Fog Light (RHD)	368
		Fuel Lid Opener (LHD)	574
		Fuel Lid Opener (RHD)	576
		Headlight (LHD)	356
		Headlight (RHD)	360
		Illumination (LHD)	412
		Illumination (RHD)	420
		Light Auto Turn Off (LHD)	452
		Light Auto Turn Off (RHD)	458
		Luggage Compartment Door Opener and Closer (LHD)	566
		Luggage Compartment Door Opener and Closer (RHD)	570
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
7.5A	MPX-B3	Power Tilt and Power Telescopic (LHD)	738
		Power Tilt and Power Telescopic (RHD)	742
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
		Rear Fog Light (LHD)	396
		Rear Fog Light (RHD)	400
		Remote Control Mirror (LHD)	598
		Remote Control Mirror (RHD)	606
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Taillight (LHD)	372
		Taillight (RHD)	378
		Turn Signal and Hazard Warning Light (LHD)	404
		Turn Signal and Hazard Warning Light (RHD)	408
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628
7.5A	P-ACC	Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Clock (LHD w/o LEXUS Navigation System)	810
		Clock (RHD w/o LEXUS Navigation System)	812
		LEXUS Navigation System (LHD)	842
		LEXUS Navigation System (RHD)	846
		Radio and Player (LHD)	850
		Radio and Player (RHD)	856
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
7.5A	P-CIG	Cigarette Lighter and Power Outlet (LHD)	806
		Cigarette Lighter and Power Outlet (RHD)	808
7.5A	P-IG	Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Automatic Glare-Resistant EC Mirror (LHD)	822
		Automatic Glare-Resistant EC Mirror (RHD)	824
		Climate Control Seat (LHD)	778
		Climate Control Seat (RHD)	782
		Clock (LHD w/o LEXUS Navigation System)	810
		Clock (RHD w/o LEXUS Navigation System)	812
		Key Reminder and Seat Belt Warning (LHD)	578
		LEXUS Navigation System (LHD)	842
		LEXUS Navigation System (RHD)	846
		Moon Roof (LHD)	558
		Moon Roof (RHD)	562
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Rear Air Conditioner (LHD)	902

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
7.5A	P-IG	Rear Air Conditioner (RHD)	908
		Seat Belt Warning (RHD)	582
		Seat Heater (Front) [LHD]	786
		Seat Heater (Front) [RHD]	788
		Seat Heater (Rear) [LHD w/ Rear Power Seat]	790
		Seat Heater (Rear) [LHD w/o Rear Power Seat]	794
		Seat Heater (Rear) [RHD w/ Rear Power Seat]	792
		Seat Heater (Rear) [RHD w/o Rear Power Seat]	796
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628
7.5A	RADIO NO.1	Radio and Player (LHD)	850
		Radio and Player (RHD)	856
7.5A	STR LOCK	Engine Immobiliser System and Steering Lock System (LHD w/ Smart Key System)	236
		Engine Immobiliser System and Steering Lock System (RHD w/ Smart Key System)	240
7.5A	TEL	LEXUS Navigation System (LHD)	842
		Radio and Player (LHD)	850
10A	DOME	Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Charging (LHD)	204
		Charging (RHD)	208
		Clock (LHD w/o LEXUS Navigation System)	810
		Clock (RHD w/o LEXUS Navigation System)	812
		Combination Meter (LHD)	862
		Combination Meter (RHD)	868
		Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
		Electronic Modulated Air Suspension (LHD)	694
		Electronic Modulated Air Suspension (RHD)	704
		Engine Control (LHD)	212
		Engine Control (RHD)	224
		Front Fog Light (LHD)	364
		Front Fog Light (RHD)	368
		Headlight (LHD)	356
		Headlight (RHD)	360
		Headlight Beam Level Control (LHD)	714
		Headlight Beam Level Control (RHD)	718
		Illumination (LHD)	412
		Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Key Reminder and Seat Belt Warning (LHD)	578

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
10A	DOME	LEXUS Navigation System (LHD)	842
		LEXUS Navigation System (RHD)	846
		LEXUS Park Assist (Clearance Sonar) [LHD]	726
		LEXUS Park Assist (Clearance Sonar) [RHD]	732
		Luggage Compartment Door Opener and Closer (LHD)	566
		Luggage Compartment Door Opener and Closer (RHD)	570
		Moon Roof (LHD)	558
		Moon Roof (RHD)	562
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Radio and Player (LHD)	850
		Radio and Player (RHD)	856
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
		Rear Fog Light (LHD)	396
		Rear Fog Light (RHD)	400
		Seat Belt Warning (RHD)	582
		SRS (LHD)	679
		SRS (RHD)	687
		Stop Light (LHD)	384
		Stop Light (RHD)	388
		Taillight (LHD)	372
		Taillight (RHD)	378
		VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628
10A	P RR-IG	Vibration Seat (LHD)	798
		Vibration Seat (RHD)	802
15A	HAZ	Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Turn Signal and Hazard Warning Light (LHD)	404
		Turn Signal and Hazard Warning Light (RHD)	408
15A	P S/HTR	Climate Control Seat (LHD)	778
		Seat Heater (Front) [LHD]	786
		Seat Heater (Front) [RHD]	788
25A	D DOOR	Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Illumination (LHD)	412
		Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
25A	D DOOR	Mirror Heater (LHD)	614
		Mirror Heater (RHD)	618
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Power Shoulder Belt Anchorage (LHD)	586
		Power Shoulder Belt Anchorage (RHD)	592
		Power Window (LHD)	542
		Power Window (RHD)	550
		Remote Control Mirror (LHD)	598
		Remote Control Mirror (RHD)	606
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
25A	P DOOR	Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Illumination (LHD)	412
		Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Mirror Heater (LHD)	614
		Mirror Heater (RHD)	618
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Power Shoulder Belt Anchorage (LHD)	586
		Power Shoulder Belt Anchorage (RHD)	592
		Power Window (LHD)	542
		Power Window (RHD)	550
		Remote Control Mirror (LHD)	598
		Remote Control Mirror (RHD)	606
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
25A	S/ROOF	Moon Roof (LHD)	558
		Moon Roof (RHD)	562
30A	AMP	Radio and Player (LHD)	850
30A	P P/SEAT	Power Seat (Front Passenger's Seat) [RHD]	758
30A	P S/HTR	Climate Control Seat (RHD)	782

* These are the page numbers of the first page on which the related system is shown.

Luggage Room J/B (See Page 110)

Fuse		System	Page
7.5A	LCE LP	Automatic Light Control (LHD)	444
		Automatic Light Control (RHD)	448
		Light Auto Turn Off (LHD)	452
		Light Auto Turn Off (RHD)	458
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Taillight (LHD)	372
		Taillight (RHD)	378
7.5A	RR A/C	Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
7.5A	RR ACC	Cellular Mobile Telephone (LHD)	834
		Cellular Mobile Telephone (RHD)	838
		LEXUS Navigation System (LHD)	842
		LEXUS Navigation System (RHD)	846
		Radio and Player (LHD)	850
		Radio and Player (RHD)	856
7.5A	RR ECU-B	Interior Light (LHD)	428
		Interior Light (RHD)	436
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Radio and Player (LHD)	850
		Radio and Player (RHD)	856
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	434
7.5A	RR IG	Cellular Mobile Telephone (LHD)	834
		Cellular Mobile Telephone (RHD)	838
		LEXUS Park Assist (Clearance Sonar) [LHD]	726
		LEXUS Park Assist (Clearance Sonar) [RHD]	732
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
10A	FUEL OPN	Fuel Lid Opener (LHD)	574
		Fuel Lid Opener (RHD)	576
		Luggage Compartment Door Opener and Closer (LHD)	566
		Luggage Compartment Door Opener and Closer (RHD)	570
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
15A	RR S/SHADE	Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Rear Sunshade (LHD)	818
		Rear Sunshade (RHD)	820
20A	RR DOOR LH	Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Illumination (LHD)	412
		Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Power Window (LHD)	542
		Power Window (RHD)	550
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
20A	RR DOOR RH	Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Illumination (LHD)	412
		Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Power Window (LHD)	542
		Power Window (RHD)	550
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
20A	RR S/HTR	Seat Heater (Rear) [LHD w/ Rear Power Seat]	790
		Seat Heater (Rear) [LHD w/o Rear Power Seat]	794

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
20A	RR S/HTR	Seat Heater (Rear) [RHD w/ Rear Power Seat]	792
		Seat Heater (Rear) [RHD w/o Rear Power Seat]	796
30A	P P/SEAT	Power Seat (Front Passenger's Seat) [LHD]	754
30A	RR SEAT LH	Power Seat (Rear Passenger's Seat) [LHD]	762
		Power Seat (Rear Passenger's Seat) [RHD]	770
30A	RR SEAT RH	Power Seat (Rear Passenger's Seat) [LHD]	762
		Power Seat (Rear Passenger's Seat) [RHD]	770

* These are the page numbers of the first page on which the related system is shown.