

24 LS 430 (RHD)
Cellular Mobile Telephone
Power Source
C5 CELLULAR PHONE
TELEPHONE TRANSCEIVER AND SPEAKER RELAY
T13 (A), T14 (B), T15 (C)
To A/C Control Assembly <29–14>
See Radio and Player System<26–6>
J30 JUNCTION CONNECTOR
Quarter panel RH
Left side of shift lever
O 6 OVERHEAD J/B
J 9 JUNCTION CONNECTOR
J 3 (A), J 4 (B) JUNCTION CONNECTOR
LH side of cylinder head
C13 COMBINATION SW
7. 5A RR ACC
7. 5A RR IG
L–IG1 RELAY
L–ACC RELAY
LUGGAGE ROOM J/B ECU
See Multiplex Communication System(J/B ECU)<2–38>
J24 JUNCTION CONNECTOR
Quarter panel LH
50A LUG J/B
J28 (A), J29 (B) JUNCTION CONNECTOR
7. 5A TEL
80A D–J/B
140A ALT
BATTERY