


LOCATION

FL Block Assy *3

- D/C CUT Fuse
- ALT H-fuse
- D-J/B H-fuse
- P-J/B H-fuse



ECM

Passenger Side J/B *3


- D DOOR Fuse
- MPX-B1 Fuse

Driving Position Memory Switch *3

Transponder Key ECU*1 *3

Gateway ECU *3

Theft Deterrent ECU *3



Driver Door ECU *3

Driver Side J/B *3

- IG1 Relay
- MPX-IG Fuse
- D-P/SEAT Fuse
- AM1 Fuse
- D-RR-IG Fuse

Steering Lock ECU*2 *3

*1: w/o Smart Key System

*2: w/ Smart Key System

*3: For RHD vehicles, look at the same location on the opposite side of the vehicle.

