










INSTRUMENT PANEL COMPONENTS

B0320-01





HINT:
Screw shapes and sizes are indicated in the table below. The codes ("A"–"M") correspond to those indicated on the previous pages.

mm (in.)								
Code	Shape							Size
Ⓐ								L = 90 (3.54) ø = 8 (0.31)
Code	Shape	Size	Code	Shape	Size	Code	Shape	Size
Ⓑ		L = 20 (0.79) ø = 8 (0.31)	Ⓒ		L = 20 (0.79) ø = 8 (0.31)	Ⓓ		L = 25 (0.98) ø = 6 (0.24)
Ⓔ		L = 20 (0.79) ø = 6 (0.24)	Ⓕ		L = 16 (0.63) ø = 6 (0.24)	Ⓖ		L = 16 (0.63) ø = 6 (0.24)
Ⓗ		L = 14 (0.55) ø = 6 (0.24)	Ⓘ		L = 14 (0.55) ø = 5 (0.20)	Ⓙ		ø = 8 (0.31)
Ⓚ		ø = 6 (0.24)	Ⓛ		ø = 6 (0.24)	Ⓜ		ø = 6 (0.24)