


REAR SEAT (Power Adjuster Type) COMPONENTS

B03ZY-01

RH side:




N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part


H16987

LH side:



N·m (kgf·cm, ft·lbf) : Specified torque

Rear Seat Adjuster



P **N·m (kgf·cm, ft·lbf) : Specified torque**