


ENGINE

HOW TO PROCEED WITH TROUBLESHOOTING

DI63H-07

When using hand-held tester, troubleshoot in accordance with the procedure on the following page.



When not using hand-held tester, troubleshoot in accordance with the procedure on the following page.

