


COOLING FAN SYSTEM

PARTS LOCATION



PROBLEM SYMPTOMS TABLE

COOLING FAN SYSTEM

Symptom	Suspected area	See page
Cooling fan is malfunctioning	1. Cooling fan motor(s)	CO-3
	2. Cooling fan ECU *1, *2	CO-3
	3. wire harness (ECM (RFC) to cooling fan ECU (SI)) *3	-
	4. wire harness (Power distributor (FCL) to cooling fan ECU (+B))	-
	5. Wire harness (Power distributor (FCB) to cooling fan fuse) *4	-

*1: Terminal SI of the cooling fan ECU is faulty, inspect the wire harness.

*2: Terminal +B of the cooling fan ECU is faulty, inspect the wire harness.

*3: If the wire harness is normal, replace the ECM.

*4: If the wire harness is normal, inspect the power distributor.