

## GROUP 54

# CHASSIS ELECTRICAL

## GENERAL

### OUTLINE OF CHANGES

The fuel average consumption and fuel instant consumption indicating functions have been added to the multi-function digital odometer. To correspond to this, the following maintenance service procedures have been established.

## TROUBLESHOOTING


### INSPECTION CHART FOR TROUBLE SYMPTOMS

Trouble symptom	Inspection procedure	Reference page
Only fuel average consumption and fuel instant consumption indications do not function.	1	54-1

### INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS

#### Inspection Procedure 1

Only fuel average consumption and fuel instant consumption indications do not function.	Probable cause
The cause is probably a malfunction of the fuel consumption signal input system.	<ul style="list-style-type: none"> <li>Malfunction of the engine-ECU</li> <li>Improper connector contact, open circuit or short-circuited harness wire</li> <li>Malfunction of the combination meter</li> </ul>



**NOTES**