

When the camshaft is installed, apply engine oil on the sliding parts.

