



Detonation Sensor Circuit

A-122



Detonation sensor

2

1



R

B

20

21

A-34



Engine-ECU

Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple