




Detonation Sensor Circuit

A-122 <135>



A-122 <4A9>
(MU802722)



Detonation sensor

2

1



R

B

20

21

A-08



Engine-ECU or engine-A-M/T-ECU

Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Grey
R: Red P: Pink V: Violet PU: Purple