

Manifold absolute pressure sensor
Intake air temperature sensor
Engine coolant temperature sensor
Accelerator pedal position sensor
Camshaft position sensor
Crank angle sensor
Ignition switch-ST
Detonation sensor

Engine-ECU

