


Keyless Entry System Function Circuit

ETACS-ECU



INPUT SIGNAL

- ALL OF THE DOOR SWITCHES
- DRIVER'S DOOR LOCK ACTUATOR SWITCH
- KEYLESS ENTRY TRANSMITTER BUTTON
- KEY REMINDER SWITCH<RH drive vehicles>