

Front impact
sensor (RH)

Front impact
sensor (LH)

Shock
above a
certain
level

SRS-ECU

Ignition signal

Ignition judgment

Passenger's air bag
cut off switch

Passenger's air bag
off indicator lamp

**Frontal collision against
another vehicle**

or
**Frontal collision against a
solid surface**

