

Tail lamp or
headlamp

ON

OFF

Key
reminder
switch

ON

(Key removed)

OFF

(Key inserted)

Driver's
door
switch

ON (Open)

OFF (Closed)

Buzzer
output

ON (Tone alarm
sounds)

OFF (Tone alarm
does not sound)

AC101512AB

