


Connectors: B-231, B-233

<R.H. drive vehicles>



Harness side

B-231

18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21	20	19

Harness side

B-233

59	58	57	56	55	54	53	52	51
68	67	66	65	64	63	62	61	60
74	73	72				71	70	69