



Connectors: B-210, B-212

<L.H. drive vehicles>

Junction block (Front view)



Harness side

B-210

7	6	5	4	3	2	1
14	13	12	11	10	9	8

B-212

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17