



SRS-ECU
(B-109)

SIDE IMPACT SENSOR (LH) (C-19)




SIDE IMPACT SENSOR (RH) (C-30)




<VEHICLES WITH CURTAIN AIR BAG>


CURTAIN AIR BAG MODULE (SQUIB) (LH) (C-08)




CURTAIN AIR BAG MODULE (SQUIB) (RH) (C-06)




NOTE
*: CONNECTOR LOCK SWITCH
(CONNECTOR COUPLED: ON
(CONNECTOR UNCOUPLED: OFF))




SIDE-AIRBAG MODULE (SQUIB) (LH) (C-20-1)



SIDE-AIRBAG MODULE (SQUIB) (RH) (C-04-1)





FRONT IMPACT SENSOR (RH) (A-21)



FRONT IMPACT SENSOR (LH) (A-16)

4
B
14



Wire colour code
B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
BR : Brown O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver