

7


# WIRING HARNESS ROUTING DIAGRAM

WIRING HARNESS ROUTING DIAGRAM ..... 7-2

7


## WIRING HARNESS ROUTING DIAGRAM

Hoses may be located in closed cross section components due to the body construction. When replacing these components, first remove the hoses.



31A0179

### 1. Drain hose (Vehicles with sunroof)



### 1. Drain hose (Vehicles with sunroof)

