




Exploded View

SEC. 270-274-276



①	Heater & cooling unit assembly	②	O-ring	③	Internal heat exchanger pipe
④	High-pressure pipe	⑤	Refrigerant pressure sensor	⑥	Washer seal
⑦	Condenser & liquid tank assembly	⑧	A/C compressor	⑨	Low-pressure flexible hose
⑩	High-pressure flexible hose				
	: Clip				
	: Always replace after every disassembly.				
	: N·m (kg·m, in-lb)				
	: N·m (kg·m, ft-lb)				