

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

Display contents of M.U.T.-III SE	Fail-safe
B2C95-01: Combination switch	Turns ON the headlight (LO)
B2C95-64: Combination switch	Turns ON the headlight (LO)
B2C96-49: Light sensor	Turns ON the headlight (LO)
B2CB5-64: Rear wiper	Stop rear wiper power supply for 1min
B2FAE-12: Ignition relay-1	Inhibit engine cranking
B2FAE-14: Ignition relay-1	Inhibit engine cranking