

Component Description


EXPLANATIONS OF COMPONENT PARTS

Component Function Within The System


Individual Component Function

8CH CAN gateway transmits CAN signals from each network.

- Without ethernet harness connector



- With ethernet harness connector



Component Operation

Refer to [System Description](#) ➔

Component Parts Location

8CH CAN gateway is installed at behind the instrument panel. Refer to [Component Parts Location](#) ➔