

[\[Previous\]](#) [\[Next\]](#)

EVAP Canister

EVAP canister stores the generated fuel vapors in the sealed fuel tank to activated charcoals of EVAP canister when the engine is not operating or when refueling to the fuel tank.

