


[\[Previous\]](#) [\[Next\]](#)

Removal and Installation


REMOVAL

caution	Never damage the front door panel.
----------------	------------------------------------


1. Remove front door finisher. Refer to [Removal and Installation](#) .
2. Disconnect door mirror assembly harness connector ①.




3. Disconnect side camera harness connector (A) (with side camera).
4. Remove front door sealing screen (B). Refer to [Removal and Installation](#) .




5. Remove harness clip ①.




6. Remove blind cap ①.



7. Remove door mirror assembly mounting bolts ①.



8. Disengage door mirror assembly fixing pawl, and then remove door mirror assembly.



INSTALLATION

Note the following item, and then install in the reverse order of removal.

caution

Perform side camera image calibration (with side camera). Refer to [Work Procedure](#) .