

BODY

CONTENTS

SPECIAL TOOLS

HOOD

REMOVAL AND INSTALLATION
INSTALLATION SERVICE POINTS

TRUNK LID

REMOVAL AND INSTALLATION
REMOVAL SERVICE POINTS
INSTALLATION SERVICE POINTS
INSPECTION

TAILGATE

REMOVAL AND INSTALLATION
REMOVAL SERVICE POINTS
INSTALLATION SERVICE POINTS

FENDER

REMOVAL AND INSTALLATION

FUEL FILLER DOOR

REMOVAL AND INSTALLATION
INSPECTION

WINDSHIELD AND WINDOW GLASS

WINDOW GLASS

GENERAL

WINDSHIELD

REMOVAL AND INSTALLATION
REMOVAL SERVICE POINTS
INSTALLATION SERVICE POINTS

REAR WINDOW GLASS

REMOVAL AND INSTALLATION

INSTALLATION SERVICE POINTS

TAILGATE WINDOW GLASS

REMOVAL AND INSTALLATION
REMOVAL SERVICE POINTS

INSTALLATION SERVICE POINTS

REAR QUARTER WINDOW GLASS

REMOVAL AND INSTALLATION

DOOR ASSEMBLY

REMOVAL AND INSTALLATION
INSTALLATION SERVICE POINTS
INSPECTION

DOOR TRIM AND WATERPROOF FILM

DOOR GLASS AND REGULATOR

REMOVAL AND INSTALLATION
INSTALLATION SERVICE POINTS
INSPECTION

ON-VEHICLE SERVICE

DOOR FIT ADJUSTMENT
DOOR GLASS ADJUSTMENT
CIRCUIT BREAKER (INCORPORATED IN THE
POWER WINDOW MOTOR) INSPECTION

DOOR HANDLE AND LATCH

REMOVAL AND INSTALLATION
INSPECTION

ON-VEHICLE SERVICE

INSIDE HANDLE PLAY ADJUSTMENT
OUTSIDE HANDLE PLAY CHECK

**DOOR BELT LINE MOULDING AND DOOR
OPENING WEATHERSTRIP**

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINTS

INSTALLATION SERVICE POINTS

SUNROOF

SERVICE SPECIFICATIONS

TROUBLESHOOTING

CHECKING THE SUNROOF ECU TERMINALS

ON-VEHICLE SERVICE

WATER TEST

SUNROOF FIT ADJUSTMENT

SUNROOF

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINTS

INSTALLATION SERVICE POINTS

INSPECTION

DISASSEMBLY AND REASSEMBLY