

QUICK REFERENCE INDEX

ENGINE FUEL & EMISSION CONTROL SYSTEM	EF & EC
AUTOMATIC TRANSMISSION	AT
FRONT AXLE & FRONT SUSPENSION	FA
BRAKE SYSTEM	BR
BODY	BF
HEATER & AIR CONDITIONER	HA
ELECTRICAL SYSTEM	EL

1994 NISSAN TRUCK & PATHFINDER

MODEL D21 SERIES

FOREWORD

This supplement contains information concerning necessary service procedures and relevant data for the model D21 series.

All information, illustrations and specifications contained in this supplement are based on the latest product information available at the time of publication. If your NISSAN model differs from the specifications contained in this supplement, consult your NISSAN distributor for information.

The right is reserved to make changes in specifications and methods at any time without notice.

HOW TO USE THIS MANUAL

- ▶ This Service Manual Supplement contains all wiring diagrams and harness layouts, revised or not, for the 1994 NISSAN TRUCK & PATHFINDER, model D21 series.
- ▶ Please use this manual in conjunction with the 1994 NISSAN TRUCK & PATHFINDER, model D21 series Service Manual (Pub. No.: SM4E-0D21U0), which includes all necessary service procedures, service data and specifications.

DO NOT USE ANY WIRING DIAGRAMS OR HARNESS LAYOUTS INCLUDED IN THE 1994 NISSAN TRUCK & PATHFINDER, MODEL D21 SERIES SERVICE MANUAL (Pub. No.: SM4E-0D21U0).

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately.

Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first completely satisfy himself that neither his safety nor the vehicle's safety will be jeopardized by the service method selected.