

DTC P0335 CKP SENSOR (POS)





[QR20(WITH EURO-OBD)]

EBS00MXD

Wiring Diagram

To ESM

EC-POS-01



TBWA0410E

AIR CONDITIONER CONTROL

[YD]

AIR CONDITIONER CONTROL



PFP:27500

Wiring Diagram


To ESM

EBS0035Z


EC-A/CCUT-01




(E5) L



(E106) BR



(F5) DGY



(F34) W



REFER TO THE FOLLOWING.

(E103) -FUSE BLOCK-JUNCTION BOX (J/B)