



POWER WINDOW SYSTEM

Wiring Diagram – WINDOW – (RHD models)

EIS00462

GW-WINDOW-05



REFER TO THE FOLLOWING.

(M2) -FUSE BLOCK-JUNCTION
BOX (J/B)