





Wiring Diagram — SROOF —

EIS000MM

RF-SROOF-01

⬡ : LHD MODELS
⬢ : RHD MODELS



REFER TO THE FOLLOWING.

(M2) -FUSE BLOCK-JUNCTION BOX (J/B)