

SECTION **IDX**

ALPHABETICAL INDEX

A

A/C control operation (auto A/C)	HA-3004
A/T - Wiring diagram	AT-3004
ABS - Wiring diagram	BR-3006
APS - Wiring diagram	EC-3016
Accelerator position sensor	EC-3016
Alternator	EL-3040
Anti-lock brake system - Wiring diagram	BR-3005
Audio	EL-3109

B

Battery	EL-3037
---------------	---------

C

CD/CHG - Wiring diagram	EL-3117
CHARGE - Wiring diagram	EL-3039
CIGAR - Wiring diagram	EL-3104
CLOCK - Wiring diagram	EL-3119
COMPAS - Wiring diagram	EL-3083
CONSULT general information	GI-3002
COOL/F - Wiring diagram	EC-3006
Charging system	EL-3039
Cigarette lighter	EL-3104
Clock	EL-3119
Combination meter	EL-3079
Combination switch	EL-3034
Cooling fan control	EC-3006

D

D/LOCK - Wiring diagram	EL-3121
DEICER - Wiring diagram	EL-3106
DTRL - Wiring diagram	EL-3044
Daytime light system	EL-3044
Dimensions	GI-3007
Dome light - See Interior lamp	EL-3069

E

ECCS-D control module	EC-3017
EGR - Wiring diagram	EC-3018
EGR volume control valve	EC-3018
Electrical units location	EL-3172
Electronic fuel injection pump	EC-3015
Engine control circuit diagram	EC-3002

F

F/FOG - Wiring diagram	EL-3052, 3053
------------------------------	---------------

Fog lamp, front	EL-3052
Front disc brake	BR-3002
Front fog lamp	EL-3052
Front washer	EL-3100
Front wiper	EL-3100
Fuel gauge	EL-3079
Fuse	EL-3213
Fusible link	EL-3213

G

Gauges	EL-3079
Ground distribution	EL-3017

H

H/AIM - Wiring diagram	EL-3042
H/LAMP - Wiring diagram	EL-3041
HLC - Wiring diagram	EL-3101
Harness layout	EL-3179
Hazard warning lamp	EL-3058
Headlamp aiming control	EL-3042
Headlamp washer	EL-3101
Headlamp	EL-3041
Height (Dimensions)	GI-3007

I

ILL - Wiring diagram	EL-3063
Illumination	EL-3062
Interior lamp	EL-3069

K

Keyless entry system - See Multi-remote control system	EL-3144
--	---------

L

Length (Dimensions)	GI-3007
License lamp	EL-3046
Location of electrical units	EL-3172
Luggage room lamp	EL-3069

M

MAFS - Wiring diagram	EC-3004
MAIN - Wiring diagram	EC-3003
MULTI - Wiring diagram	EL-3145
Meter	EL-3079
Model variation	GI-3004

ALPHABETICAL INDEX

Multi-remote control system EL-3144

N

NATS (Nissan Anti-theft System) EL-3168

NATS - Wiring diagram EL-3168, 3169, 3171

P

POWER - Wiring diagram EL-3007

Parking brake control BR-3004

Parking lamp EL-3046

Power door lock EL-3120

Power supply routing EL-3006

R

R/COOL - Wiring diagram (front
auto A/C) HA-3008

ROOM/L - Wiring diagram EL-3070

Radio - See Audio EL-3109

Rear axle (drum brake type) RA-3002

Rear disc brake BR-3003

Rear window defogger EL-3107

Refrigeration cycle HA-3003

Room lamp - See Interior lamp EL-3069

S

S/LOCK - Wiring diagram EL-3134

S/TANK - Wiring diagram FE-3004

STAB - Wiring diagram RA-3003

Speedometer EL-3079

Stabilizer release device - Wiring
diagram RA-3003

Stabilizer release device RA-3003

Starter EL-3038

Starting system EL-3038

Steering switch EL-3036

Steering wheel and column ST-3002

Sub fuel tank control system FE-3002

Super lock EL-3133

Supplemental restraint system - Wiring
diagram RS-3003, 3007

T

TAIL/L - Wiring diagram EL-3046

TCM circuit diagram AT-3003

THEFT - Wiring diagram EL-3157, 3162

TURN - Wiring diagram EL-3058

Tachometer EL-3079

Tail lamp EL-3046

Theft warning system EL-3156

Tread-FR&RR (Dimensions) GI-3007

Turn signal lamp EL-3058

V

VSS - Wiring diagram EC-3005

Vehicle identification number GI-3006

Vehicle speed sensor (VSS) EC-3005

W

WARN - Wiring diagram EL-3086

WIPER - Wiring diagram EL-3100

Warning chime EL-3098

Warning lamps EL-3084

Washer, front EL-3100

Water temperature gauge EL-3079

Wheelbase (Dimensions) GI-3007

Width (Dimensions) GI-3007

Wiper deicer EL-3106

Wiper, front EL-3100