

SECTION

RA

- MODIFICATION NOTICE:**
- Tightening torque for bearing cage has been changed.
 - Wiring diagrams have been changed.

CONTENTS

REAR AXLE.....	3002	STABILIZER RELEASE DEVICE.....	3003
Components.....	3002	Wiring Diagram	3003

REAR AXLE

Components

DRUM BRAKE TYPE


SEC. 430

TB48 engine

105 - 135 (11 - 13, 78 - 99)

Except TB48 engine

54 - 74 (5.5 - 7.5, 40 - 54)



⌚ : N•m (kg-m, ft-lb)





⌚ 118 - 147 (12 - 15, 87 - 108)

RA-3002

SRA887A

STABILIZER RELEASE DEVICE

Wiring Diagram



Refer to last page (Foldout page).

(M21), (E127)

M3

STABILIZER RELEASE DEVICE

Wiring Diagram (Cont'd)

RA-STAB-02

- L : LHD models
- R : RHD models
- BE : TB48 engine models
- ZD : ZD engine models

- *1 4M: L
- 10: R
- *2 3M: L
- 13: R
- *3 17M: L
- 11: R

