


GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

1. General Description

A: COMPONENT

1. FRONT BUMPER




- | | |
|----------------------------|---------------------------|
| (1) Bumper face | (5) Side bracket |
| (2) Bumper energy absorber | (6) Cover (Tie down hook) |
| (3) Bumper beam | (7) Cover |
| (4) Side stay | |

Tightening torque: N·m (kgf-m, ft-lb)

T: 33 (3.4, 25)

2. REAR BUMPER (SEDAN)



EI-00117

- (1) Bumper beam
- (2) Upper beam
- (3) Resin beam
- (4) Side bracket

- (5) Bumper face
- (6) Hook
- (7) Side stay


Tightening torque: N·m (kgf-m, ft-lb)

T: 95 (9.7, 70)

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

3. REAR BUMPER (WAGON)




- (1) Bumper beam
- (2) Resin beam
- (3) Side bracket

- (4) Bumper face
- (5) Hook
- (6) Side stay

Tightening torque: N·m (kgf-m, ft-lb)

T: 95 (9.7, 70)

4. REAR BUMPER (PICKUP)



EI-00691

- (1) Bumper beam
- (2) Bumper energy absorber
- (3) Bumper face

- (4) Side lower cover
- (5) Side bracket
- (6) Lower cover


Tightening torque: N·m (kgf-m, ft-lb)

T: 95 (9.7, 70)

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

5. SIDE PROTECTOR



EI-00241

(1) Side garnish (Front fender)


(2) Side garnish (Front door)

(3) Side garnish (Rear door)

(4) Side garnish (Rear quarter)

(5) Side garnish (Side sill)

6. ROOF RAIL




- (1) Roof rail
- (2) Roof molding
- (3) Clip

Tightening torque: N·m (kgf-m, ft-lb)
T: 7.5 (0.76, 5.53)

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM


7. DOOR TRIM



EI-00120

- | | | |
|------------------------|-------------------------------|-----------------|
| (1) Gusset cover | (5) Pad | (9) Upper trim |
| (2) Bracket | (6) Trim panel | (10) Side trim |
| (3) Weatherstrip upper | (7) Power window switch cover | (11) Lower trim |
| (4) Clip | (8) Weatherstrip lower | |

8. INNER TRIM (SEDAN)




EI-00121

- | | | |
|------------------------------|--------------------------------|----------------------------------|
| (1) Front pillar upper trim | (6) Trunk rear trim | (11) Side sill rear lower cover |
| (2) Center pillar upper trim | (7) Trunk side trim | (12) Front pillar lower trim |
| (3) Rear pillar upper trim | (8) Rear pillar lower trim | (13) Side sill front lower cover |
| (4) Rear shelf trim | (9) Side sill rear upper cover | (14) Pad stopper A pillar |
| (5) Rear bulk trim | (10) Center pillar lower trim | (15) Pad B pillar upper |

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM


9. INNER TRIM (WAGON)



EI-00122

- | | | |
|------------------------------|---------------------------------|----------------------------------|
| (1) Front pillar upper trim | (7) Lid | (13) Front pillar lower trim |
| (2) Center pillar upper trim | (8) Rear skirt trim | (14) Side sill front lower cover |
| (3) Rear pillar upper trim | (9) Hook | (15) Pad stopper A pillar |
| (4) Rear rail trim | (10) Side sill rear upper cover | (16) Pad B pillar upper |
| (5) Pocket | (11) Center pillar lower trim | |
| (6) Rear quarter lower trim | (12) Side sill rear lower cover | |

10.INNER TRIM (PICKUP)




EI-00692

- | | | |
|------------------------------|---------------------------------|----------------------------------|
| (1) Front pillar upper trim | (7) Hook | (13) Front pillar lower trim |
| (2) Center pillar upper trim | (8) Cover | (14) Side sill front lower cover |
| (3) Rear pillar upper trim | (9) Floor trim panel | (15) Pad stopper A pillar |
| (4) Rear pillar lower trim | (10) Side sill rear upper cover | (16) Pad B pillar upper |
| (5) Lid | (11) Center pillar lower trim | |
| (6) Rear bulk head trim | (12) Side sill rear lower cover | |

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

11.CARGO BED TRIM




EI-00693

- | | |
|--------------------------------|--------------------------|
| (1) Cargo bed upper molding | (6) Tail gate tray |
| (2) Cargo bed C pillar molding | (7) Cargo bed floor tray |
| (3) Cargo bed side molding | (8) Back panel tray |
| (4) Cargo bed side tray | (9) Clip |
| (5) Tail gate molding | (10) Clip |

Tightening torque: N·m (kgf-m, ft-lb)

T: 7.5 (0.76, 5.53)

12. INSTRUMENT PANEL



EI-00123


- | | | |
|---------------------------|-----------------------|----------------------|
| (1) Pad & frame | (11) Front cover (MT) | (21) Switch panel |
| (2) Grille side (D) | (12) Rear cup holder | (22) Meter visor |
| (3) Hook | (13) Console box | (23) Grille vent (D) |
| (4) Grille side (P) | (14) Cap | (24) Grille center |
| (5) Grille vent (P) | (15) Console lid | |
| (6) Glove box panel | (16) Console cover | |
| (7) Glove box lid | (17) Tray | |
| (8) Center panel side (D) | (18) Ash tray | |
| (9) Center panel side (P) | (19) Lower cover | |
| (10) Front cover (AT) | (20) Center panel | |

Tightening torque: N·m (kgf-m, ft-lb)
T: 7 (0.7, 5.1)

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

13.INNER ACCESSORIES




EI-00124

- (1) Hook
- (2) Sun visor

- (3) Pad side rail
- (4) Assist grip

14.LICENSE PLATE BRACKET



(1) License plate bracket

(3) Side cover

(2) Upper cover

Tightening torque: N·m (kgf-m, ft-lb)

T: 7.5 (0.76, 5.53)

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

B: PREPARATION TOOL

TOOL NAME	REMARKS
Clip remover	Used for removal of trim.
Adhesive remover	Used for removal of side protector.
Primer	Used for installation of side protector.
Infrared lamp	Used for disassembly/assembly of side protector.
Tow-sided tape	Used for installation of side protector.
TORX® T30	Used for disassembly/assembly of crossbar, removal/installation of cargo bed.
TORX® T25	Used for removal/installation of cargo bed.