


CROSS SECTIONAL VIEW**3. Cross Sectional View****A: NON-TURBO MODELS**

CL-00085

CROSS SECTIONAL VIEW


CLUTCH

- | | | |
|------------------------|-----------------------------|-------------------|
| (1) Operating cylinder | (4) Clutch cover | (7) Pilot bearing |
| (2) Release lever | (5) Transmission main shaft | (8) Flywheel |
| (3) Release bearing | (6) Clutch disc | |

CROSS SECTIONAL VIEW

CLUTCH

B: TURBO MODELS



CL-00119

CROSS SECTIONAL VIEW

CLUTCH

-
- | | | |
|------------------------|-----------------------------|----------------------|
| (1) Spring bracket | (5) Flywheel | (9) Pilot bearing |
| (2) Spring | (6) Clutch cover | (10) Release bearing |
| (3) Release lever | (7) Clutch disc | |
| (4) Operating cylinder | (8) Transmission main shaft | |