


5. Hydraulic Clutch Pedal System

A: CONSTRUCTION

- The hydraulic clutch pedal is connected to the master cylinder via a rod.
- The clutch pedal and brake pedal are mounted on the same bracket.
- The clutch pedal has a mechanism that reduces (assists) the force required to depress the clutch pedal and reduce the initial pedal depressing force.
- A starter interlock mechanism is provided to prevent the engine from starting unless the clutch pedal is pressed.



CL-00272

- | | |
|------------------------------------|---|
| (1) Clutch pedal | (4) Rod |
| (2) Brake pedal | (5) Lever |
| (3) Brake and clutch pedal bracket | (6) Initial pedal effort reducing mechanism |

HYDRAULIC CLUTCH PEDAL SYSTEM


CLUTCH

B: OPERATION

1. STARTER INTERLOCK MECHANISM

When the clutch pedal is fully depressed, the stopper on the pedal pushes the clutch switch pushrod inwards.

When the pushrod is pressed in, the switch turns ON and connects the ignition switch to the starter circuit enabling engine start.



CL-00138


(A) When clutch switch is OFF

- (1) Clutch switch
- (2) Stopper

(B) When clutch switch is ON

- (3) Clutch pedal
- (4) Pushrod

- Schematic drawing



CL-00137

- (1) Ignition switch
- (2) Starter relay

- (3) Clutch switch
- (4) Starter motor

HYDRAULIC CLUTCH PEDAL SYSTEM

CLUTCH

MEMO