



3. Baja

A: REAR BUMPER

- Due to redesigning of the vehicle's rear end, the rear bumper's contour has become unique to the pickup.
- The new bumper beam assembly is designed specially for the pickup.



EI-00273

**A-A****B-B**

EI-00274


(1) Bumper face

(2) Bumper beam

(3) E/A foam

B: ROOF RAILS

The aluminum roof rails are mounted directly on the roof and are designed specially for the pickup.




EI-00275

C: CARGO BED

1. BED TRAY

- The bed tray area is covered with a plastic resin (PP) tray to prevent damages to the body.
- Projection of the wheel houses into the cargo bed area is minimized to achieve a floor area as wide as possible.



EI-00276

(1) Back panel tray

(4) Floor tray


(2) Switch back tray

(5) Tailgate tray

(3) Side tray

2. MOLDING

The cargo bed's edges are covered with plastic resin (PC/PBT) to prevent damage to the body.




EI-00277

3. DRAIN HOLES


The floor tray is designed as follows to prevent accumulation of rain, etc.

- The floor tray is slanted toward the front of the vehicle. This slant allows rain etc. to run toward the front of the floor tray.
- There are 2 drain holes provided at the front end of the floor tray. Water flowing toward the front of the vehicle is drained through the drain holes.
- The excessive water that couldn't be drained through the drain holes will flow along the drain guide to the rear of the vehicle and get drained there.



EI-00278

- (1) Drain hole
- (2) Drain guide




EI-00279


- (A) Drain hole upper view
- (B) Drain hole lower view

D: REAR SEAT CONSOLE BOX

Cup holders and a console box are provided at the center of the rear seat cushion for rear seat occupants.



- (1) Cup holders
- (2) Storage box

E: REAR BULKHEAD PANEL

(1) Rear seat head rest

(2) Switch back


(3) Switch back release lever

(4) C pillar lower pocket

EI-00281

1. SWITCH BACK GATE

- The switch back gate can be opened by pulling the switch back release lever.




EI-00282

(A) Closed

(1) Switch back release lever

(B) Open


- When the switch back gate is open, an indicator light in the combination meter illuminates.



IDI00045


2. C PILLAR LOWER POCKET


Storage pockets are provided adjacent to both sides of the switch back gate which is located at the rear of the rear seat. The jack and standard tools are stored in the driver's side pocket.



F: FUEL FLAP

Due to redesigning of the vehicle's rear end, an ABS fuel lid designed specially for pickup trucks is used.



G: LICENSE PLATE BRACKET

EI-00394


(1) License plate light

To keep the license plate visible even when the tailgate is regularly kept open with the accessory extender, a movable license plate bracket is provided.

The license plate bracket is equipped with a license plate light.

Operation


Push the buttons on each side of the license plate to release locks.



EI-00395

(1) Release button

Raise the license plate.



EI-00397

BAJA

EXTERIOR/INTERIOR TRIM

Open the tailgate.

