


2. Rear


A: GENERAL

Sedan models



LI-00318

Wagon models




LI-00319

(1) Backup light	(5) Turn signal/hazard warning light
(2) Stop/tail/parking/rear side marker light	(6) Rear finisher light
(3) License plate light	(7) Rear combination light
(4) High mount stop light	(8) Stop/tail/parking light

REAR

LIGHTING SYSTEM

- The rear turn signal/hazard warning light, stop/tail/parking light, and the backup light are incorporated into the rear combination light and rear finisher light. The side marker light and rear reflex reflector are also incorporated into the rear combination light.
- The high mount stop light is installed to the bottom inside of the rear window on sedans, and to the top inside of the rear gate on wagons.

B: BAJA


(1) High mount stop light	(4) Stop/turn signal/tail light
(2) Cargo light	(5) Tail light
(3) Backup light	(6) License plate light

- The backup light and stop/turn signal/tail light are built into the rear combination light. The turn signal light is also used as the stop light.
- The rear finisher light contains a tail light.
- The license plate bracket is equipped with a license plate light.
- The cargo bed upper molding is equipped with a high mount stop light and a cargo light.

REAR

LIGHTING SYSTEM

- The cargo light switch is located at the left side of the driver's seat. When the cargo light is ON, an indicator light in the combination meter illuminates.



LI-00126



IDI00047