

### 8. Inspection Mode

#### A: PROCEDURE

Recreate the condition by referring to the fault conditions described in the check list.