


# General Description

## CRUISE CONTROL SYSTEM

### 1. General Description

#### A: COMPONENT



(1) Cruise indicator and cruise set indicator light	(3) Cruise control command switch	(6) Stop light & brake switch
(2) Inhibitor switch (AT model)	(4) Engine control module (ECM)	(7) Neutral position switch (MT model)
(5) Clutch switch (MT model)		

CC-00315

## B: CAUTION

- Before disassembling or reassembling parts, always disconnect the battery ground cable from battery. When repairing the radio, control module, etc. which are provided with memory functions, record the memory contents before disconnecting the ground cable from battery. All memory is cleared.
- Reassemble the parts in the reverse order of disassembly unless otherwise indicated.
- Adjust the parts to specifications specified in this manual.
- Connect the connectors and hoses securely during reassembly.
- After reassembly, ensure functional parts operate properly.

## C: PREPARATION TOOL

TOOL NAME	REMARKS
Circuit tester	Used for measuring resistance and voltage.
TORX® bit T30	Used for removing the cruise control command switch.